Installing the solar spot light in the ground

NOTE: Do not use a hammer. If the ground is hard, use water to soften or a trowel to loosen the soil.

- Open the battery cover (FF) of the spotlight head (A) to remove pull tab (first time users only).
- Push the assembly (A) into the ground.



Replacing the battery

CAUTION: When replacing the battery, use one (1) 400mAh LiFePO4, 14430, 3.2V rechargeable battery.

IMPORTANT: Dispose of the batteries in accordance with local, state, and federal regulations.

- Open the battery cover.
- Replace the old battery with a fresh 400mAh LiFePO4, 14430, 3.2V rechargeable battery.
- Replace the battery cover.



Charging the battery

- For optimum performance, it is best to install the solar light in full sunlight and let it charge for 10-12 hours.
- Allow the light to run at least 8-12 entire charging and discharging cycles to reach the maximum capacity of the battery.

Winter tips

- Keep debris and snow off the solar panel to allow the battery to recharge. If lights have been covered by snow for a long time, allow the battery to recharge in full, direct sunlight for at least 10-12 hours so it can maintain maximum capacity.